



Weather Bulb Strip Installation Instructions

****Stairways manufactured after March 17, 2008 are manufactured with a pre-cut groove in the box framing along three sides of the framing. Stairs produced before this date do not include the pre-cut groove in the box framing****

1. Start inserting the weather strip at the top right corner near the head board end of the stair. Make sure the bulb is facing down toward the plywood and the spline (hooked edge) of the weather strip is securely fastened into the kerf (slot in the wood). **DO NOT LEAN OUT ON THE STAIR TO TRY AND REACH THE CLOSING END OF THE STAIR; USE A STEP LADDER TO GET THE END OF THE BOX SIDE AND THE CLOSING END OF THE STAIR TO INSTALL THE BULB WEATHER STRIP.**
2. Use a small block of wood to push the weather strip into the kerf in the box side.
3. When you reach the end board cut the weather strip off making sure the weather strip is installed all the way to the corner to prevent leakage.
4. Start the left side of the weather strip at the headboard end just like you completed the RIGHT side. Making sure you run the weather strip all the way up to the head board and all the way to the end board to prevent leakage.
5. After both sides of the boxesiding are installed, install the end board weather strip into the end board kerf (slot in the wood).
6. Take a dry clean rag and wipe the oil off the piano hinge on the inside of the headboard. When applying the flat weather strip to the piano hinge the hinge must be free of oil to allow adhesive strip to attach to piano hinge. You may apply this strip before you install the ladder or after you have completed the installation. Apply the small flat strip low enough on the piano hinge to get a good seal when the hinge is closed. By placing the strip over the slots on the piano hinge so light cannot be seen through the slots in the hinge you will get the most insulation value. This adhesive weather strip should make contact with the bulb weather strip that was previously installed for best sealing value.

If you have any questions, please feel free to call us at 501-897-5253 from 8 am – 4:30 pm CST and we will be happy to assist you.

2300 EAST 145th STREET LITTLE ROCK, ARKANSAS 72206 PHONE (501) 897-5253

Help us spread the word "Like Us" on facebook.com/CenturyIndustriesInc

Watch us on YouTube at youtube.com/user/centuryatticstair